

PendantStation(SH / 14 D)



SH / 14 D Push Buttons:

12 + 2 - Two Speed

Description :

12 Push Button with (1 NO + 1 NO)

Progressive Contacts




+ 1 Emergency Stop with 1 NC Contact

+ 1 Start /Alarm with 2 NO Contacts



SH / 14D		SH / 14D1		SH / 14D2		SH / 14D3	
START ALARM	STOP	START ALARM	STOP	START ALARM	STOP	START ALARM	STOP
UP	DOWN	UP	DOWN	UP	DOWN	UP	DOWN
UP	DOWN	UP	DOWN	UP	DOWN	UP	DOWN
FORWARD	REVERSE	FORWARD	REVERSE	FORWARD	REVERSE	FORWARD	REVERSE
FORWARD	REVERSE	FORWARD	REVERSE	FORWARD	REVERSE	FORWARD	REVERSE
LEFT	RIGHT	LEFT	RIGHT	LEFT	RIGHT	LEFT	RIGHT
LEFT	RIGHT	LEFT	RIGHT	LEFT	RIGHT	LEFT	RIGHT

Single Speed Multi Speed



Weight : 1390 gm.