

# Pendant Station(SV / 3 S, D)



## SV / 3 S Push Buttons:

**2 + 1 - Single Speed**

### Description :

**2 Push Button with 1 NO Contact**

**+ 1 Emergency Stop with 1 NC Contact**

### Single Speed



UP



DOWN

### Multi Speed



### SV / 3S

STOP



UP



DOWN

## SV / 3 D Push Buttons:


**2 + 1 - Two Speed**

### Description :

**2 Push Button with (1 NO + 1 NO)**

**Progressive Contacts**

**+ 1 Emergency Stop with 1 NC Contact**



**Weight : 450 gm.**

